

# Frame Assembly Instructions

**Tools needed:** scissors

## Step 1: Attach VELCRO® tape to frame (black hook tape goes on black frame)

Separate poles into two piles. One for horizontal and one for vertical. Vertical poles are longest.

Lay horizontal poles on a flat surface with “channel” facing up (the drilled holes in poles will be on the underside).

Match up the long pieces of black hook tape with the long poles and short pieces of tape with the short poles.

Begin with any horizontal pole and place black tape in the channel starting 1/8” in from the edge. Peel off the backing a little at a time so the sticky tape doesn’t tangle. Before laying the end of the tape down, trim it to fit 1/8” in from the end of the channel. Press tape firmly into channel.

Repeat this process for remaining horizontal poles.

## Step 2: Attach VELCRO® tape to panels (white loop tape goes on backdrop panels)

a. Remove panels from tube and lay on flat surface. Cut out notches in all four corners of each panel (see scissor symbols). Tape is to be attached to both top and bottom edges.

b. Start the white loop tape 1/8” in from side edge in the unprinted area where marked. Peel off the backing a little at a time so the sticky tape doesn’t tangle. Trim the end of the tape 1/8” in from the edge. Press tape firmly onto panels to secure adhesive.

## Step 3: Assemble Frame


Lay all frame pieces on the floor as shown in frame diagram below.

Snap the hinges and corners into the vertical curved poles first and then connect the horizontal poles on the top and bottom.


Screw feet into bottom of frame (feet are optional).

NOTE: Top horizontal poles will have the holes on top, facing the ceiling. Bottom horizontal poles will have the holes facing the floor.

## 3-Panel Setup



**NOTE:** black hook tape goes on frame, white loop tape goes on backdrop panels



**Recommended:** wait 24 hours to allow adhesive to bond to the frame and panels before final assembly.

## 3-PANEL PARTS LIST


Count all parts and make sure none are missing. Call 1-800-782-8697 **within 10 days** to report any missing part and we will replace it at no additional charge.

### Panel parts

3 panels printed on both sides

White loop tape

Black hook tape



### Frame parts

4 hinges

4 corners

4 feet

6 long poles


2 medium poles

4 short poles

(4) corners


(4) hinges

(4) feet



V= vertical H= horizontal

## 5-Panel Setup



### Step 4: Attach panels to frame

With frame standing upright in zigzag position, slide the bottom of panel #1 under the frame section in the order it belongs. Wrap the bottom of the panel around the horizontal pole and position the white loop tape onto the black hook tape and press down securely.

Pull the panel up and wrap the top of the panel around the top horizontal pole of the frame, pressing the loop and hook tape together. Repeat for each panel.

### Step 5: Enjoy your Walk-in Storybook!

#### 5-PANEL PARTS LIST

Count all parts and make sure none are missing. Call 1-800-782-8697 **within 10 days** to report any missing part and we will replace it at no additional charge.


##### Panel parts

5 panels printed on both sides (see above)  
White loop tape



##### Frame parts

8 hinges  
4 corners  
6 feet  
10 long poles  
6 medium poles  
4 short poles  
Black hook tape



3-panel theme (Farm)



5-panel theme (TV Studio)



Line up panels so that panel #1 is on the far left



calapitter  
creations™

800.782.8697

www.calapitter.com

© Calapitter Creations, Inc.